



Bluetooth® Transmitter & Receiver 2-IN-1 Wireless Audio Adapter
Caliber Air Buddy
User Guide



INTRODUCTION
Thanks for choosing our Bluetooth transmitter (TX) & receiver (RX) audio adapter. This device combines the function of wireless transmitter and receiver in one for audio streaming. In the Transmitting (TX) Mode, it streams audio wirelessly from the non-Bluetooth devices to your Bluetooth headphone or speakers. In the Receiving (RX) Mode, it streams audio to your wired speaker, headphone, car stereo or home stereo system wirelessly from your Bluetooth-enabled media player. If you want to have a better experience, please read this instruction carefully.


- PACKING CONTENTS**
- 2-IN-1 Wireless Audio Adapter
 - 3.5mm Audio Cable
 - USB-C Charging Cable
 - User Guide
 - Airplane headphone adapter
- NOTE: USB-C adapter not included

- FEATURES**
- 2-IN-1 BLUETOOTH AUDIO Transmitter & Receiver
1. Broadcast Audio Output from Your TV, CD player, or Old PC to Wireless Headphones, Speakers and Even Car Stereo System;
 2. Supreme Audio Connectivity and Quality with improved connection stability, faster pairing, and reduced power consumption for connected devices;
 3. Switch operation and audio connection modes with the simple click of the switch button;
 4. Effortlessly Enjoying up to 10 hours of use on the internal battery and rapid recharging, ready for many more;
 5. Suitable for In-car Usage as a Hands-free Car Kit;
 6. Built-in Rechargeable Battery 150mAh.

- SPECIFICATIONS**
- Bluetooth Version: 5.4
Bluetooth Distance: about 8m
TX transmitter working time: 10 hours
RX receiver working time: 12 hours
Charging time: 2 hours
Battery Capacity: 3,7V/150mAh (0,56WH)
Power input: DC 5V/500mA
Product Size: 61*27.6*14mm
Audio Jack: 3.5mm Aux, 110 mm Aux cable included
Product weight: 19g

- COMPATIBILITY**
- This device can be paired as a hands-free kit with any compatible Bluetooth enabled devices. Each time can only connect with one Bluetooth device.

- PRECAUTIONS FOR SAFETY**
- Read the following safety and operating instructions before using this product. Retain this manual for reference.
- ⚠** This symbol alerts the user of the presence of important safety warnings.
- Do not disassemble the product or insert foreign objects into it. Internal parts may be damaged or the user may be injured.
- If the product or charger overheats, if the cord or plug is damaged, if dropped or dropped into water, turn off the power and stop using it and contact customer service.
- Do not let rain, moisture or liquid come into contact to the electronic parts.
- Product cleaning.**
Use a soft dry cloth for periodic cleaning of the product. For more severe stains, please dampen the cloth with water only. Anything else has the chance of dissolving the paint or damaging the plastic.
- Observe the following charging and battery warnings to avoid electric shock, explosion, fire or leakage of corrosive or toxic chemicals.
- ⚠ CHARGING WARNINGS**
- Make sure that the rated voltage of the adapter match the product
 - Do not charge the battery where the temperature can drop below 0 degrees Celsius or rise above 40 degrees Celsius
 - turn off the product while charging
- ⚠ BATTERY WARNINGS**
- Do not dispose of the product or battery in fire or heat above 70 degrees Celsius.
 - Do not open, deform or cut the battery. Corrosive liquid may damage eyes or skin and may be toxic when swallowed.
 - Do not attempt to remove the battery"
- ⚠ HEARING SAFETY**
- For your safety, do not set the volume too high to stay aware of your surroundings.
 - Do not listen with high volume for a long time to avoid hearing damage.



- OPERATIONS INSTRUCTIONS**
- Turning on/off**
- Press and hold the large round button to turn on the Air Buddy.
 - To turn the Air Buddy off, press and hold the large round button for several seconds.

- Note:**
- Press the "Switch" button to switch between modes.
 - TX mode, transmitter mode (blue indicator light)
 - RX mode, receiver mode (green indicator light)
- Reset**
- You can reset the Air Buddy by pressing and holding the home button for 6 seconds.
- Transmitter mode (TX)**
- By default, the Air buddy is enabled in TX mode (transmitter mode), it now displays a blue indicator light.
 - The unit now automatically searches for and connects to available Bluetooth speakers, headphones or other Bluetooth devices.
 - When it starts connecting, the indicator light will flash
- Receiver mode (RX)**
- In receive mode (green indicator light) connect the Air Buddy to your speaker, DVD player, or wired headphones via the 3.5mm audio cable.
 - Pair the device via Bluetooth with your cell phone, tablet or game console, the Air Buddy can be found under the name: Caliber Air Buddy.
 - Play your music and enjoy high-quality sound through your connected speaker, stereo system or headphones.
 - Press the "HOME" button once to play or pause music.
- *The function to play or pause music does not work in transmitter mode.
- Hands-free function:**
- Press the "HOME" button once to answer or hang up an incoming phone call.
 - Press and hold the "HOME" button for 3 seconds to reject a phone call.
 - Press the "HOME" button twice to redial the last phone call.
 - During a call, press and hold the "HOME" button for 3 seconds to switch from a phone call through your speaker, to a privacy call on your phone.
- Charging the Wireless Audio Adapter**
- 1.When the battery power is low, the indicator light flashes red;
 - 2.You can charge this Bluetooth receiver with the USB-C charging cable in the package;
 - 3.In the charging status, the indicator is on solid red, and it goes off when the device is fully charged.
 - 4.Power on the unit, it will automatically power off if there is no any Bluetooth connection in the RX mode for 5 minutes.

- IMPORTANT SAFETY INSTRUCTIONS**
- ⚠** Long-term exposure to loud music or sounds may cause hearing damage.
It is also best to avoid high volume levels when using headphones/earphones, especially for extended periods.
Using headphones/earphones limits your ability to hear noise around you, regardless of listening volume. Please use caution when using headphones/earphones.
- CORRECT DISPOSAL OF THE PRODUCT**
- ⌘** According to directive 2012/19/EU. This marking on the product, accessories or literature indicates that the product and its electronic accessories should not be disposed of with other household waste at the end of their working life. To prevent possible harm to the environment of human health from uncontrolled waste disposal, please separate these items from other types of waste and recycle them responsibly to promote the sustainable reuse of material resources. Household users should contact either the retailer where they purchased this product, or their local government office, for details of where and how they can take these items for environmentally safe recycling.

- CORRECT DISPOSAL OF THE BATTERY**
- ⌘** According to European Directive (EU) 2023/1542. This marking on battery indicates that the batteries in this product should not be disposed of with other household waste at the end of their working life. If batteries are not properly disposed of, these substances can cause harm to human health or the environment. To protect natural resources and to promote material reuse, please separate batteries from other types of waste and recycle them through your local, free battery return system. When needed please ask your local free battery return system to remove the battery from the case.

DECLARATION OF CONFORMITY

We hereby declare that the items Airbuddy is in compliance with the essential requirements and other relevant provisions of Directive 2014/53/EU (RED) and 2011/65/EU (ROHS). EU Declaration:
www.calibereurope.com/nlmedia/forms/declarationairbuddy.pdf