ChargePro
20 000 mAh Power Bank
With LED Display PD 22.5 W



INSTRUCTION MANUAL

Please read these instructions carefully and retain them for future reference.



PEP-9006-BK20

HIGHLIGHTS

- 2 X Type-C Charging Ports
- 2 X USB-A Charging Ports
- Charge Up To 3 Devices Simultaneously
- Digital Display

PACKAGE CONTENTS

- Amplify™ ChargePro Series 20 000mAh Power Bank with LED Display
- USB-C Charging Cable
- Instruction Manual

SPECIFICATIONS

Model	S279L
Size	140.5 x 68.2 x28.6 mm
Weight	395g
Capacity	20000 mAh
Power Output	22.5 W Max
USB-C 1 In	5 V/2 A, 9 V/ 2 A, 12 V/ 1.5 A (18 W Max)
USB-C2 In	5 V/2.5 A, 9 V/2 A, 12 V/1.5 A (18 W Max)
USB-C2 Out	5 V/3 A 9 V/ 2.22 A, 12 V/1.67 A (20 W Max)
2 x USB-A Out	5 V/3 A, 9V/2 A, 12 V/1.5 A, 5 V/4.5 A (22.5 W Max)

IDENTIFYING PARTS



1. Digital Display
2. USB-A 2 Port
3. USB-A 1 Port
4. Power Button
5. USB-C 1 Port
6. USB-C 2 Port

CHARGING THE POWER BANK

The power bank can be charged directly through the mains socket outlet using USB charger (not supplied).

If you are using a computer/ laptop It could take longer as the maximum output load from USB 2.0 is 0.5 A. Use a USB 3.0 Port to charge faster.

CHARGING YOUR DEVICE

Plug the USB end of your cable into one of the USB Ports located at the top of the power bank. Plug the USB end of the supplied cable into the charging port on your device. The Battery LED Indicator will light up and indicate the amount of charge the power bank has left.

CONTROLS

Power Management:

1. **Battery Status**: Digital Display (Green PD symbol displays during fast charging).
2. **Charging Display**: When charging in the shutdown state, the digital tube displays 100%+ lightning symbol and enters the charging state after 0.5s, and the current power level flashes and turns on until it is charged to 100%. When charging in the boot state, the digital tube shows the current power level and flashes in single digits, and it will always turn on when it is charged to 100%. When fast charging, the lightning symbol is always on.
3. **Discharge Display**: When discharging,the digital tube shows that the current power is always on, and flashes when the power is as low as 5%. The lightning bolt symbol is always on when it is released.
4. Low Battery Alarm: In the discharge state, the digit blinks when the battery is on 5%.

CLEANING AND CARE INSTRUCTIONS - GENERAL

- **Before Cleaning:** Ensure that your Amplify™ ChargePro Series 20 000 mAh Powerbank With LED Display is turned off and disconnected before cleaning or maintaining it.
- **Cleaning:** Wipe down the surface of your Power Bank using a soft, slightly damp cloth.
- Do not use any harsh or abrasive cleaning chemicals or materials on your Power Bank as doing so may damage or scratch the surface finish.
- Do not store in temperatures over 60 °C. Do not expose the battery to excessive heat such as sunshine, fire or the like. Store in a cool, dry place.

SAFETY PRECAUTIONS

- Ensure responsible use of this power bank.
- Unplug the power bank when not in use.
- Do not attempt to use this power bank when performing tasks that require your full attention.
- Do not expose this power bank or any of its components to water, fire, high temperatures or damp areas.
- Do not disassemble this power bank.
- Keep out of reach of children.
- Operate between 0 ° ~ 40 °C.
- Do not cover the power bank i.e.: use beneath pillows or blankets.
- Do not store in temperatures over 140 °F (60 °C).
- Do not attempt to charge your Power Bank whilst charging a device.

DISCLAIMER

All product and company names are trademarks™ or registered® trademarks of their respective holders. Use of them does not imply any affiliation with or endorsement by trademark or registration holders.

ENVIRONMENTALLY FRIENDLY DISPOSAL

IMPORTANT INFORMATION FOR CORRECT DISPOSAL OF THE PRODUCT IN ACCORDANCE WITH THE SOUTH AFRICAN DIRECTIVE ON WASTE ELECTRICAL AND ELECTRONIC EQUIPMENT.

- At the end of its working life, the product must not be disposed of as urban waste. It must be taken to a special local authority differentiated waste collection centre or to a dealer providing this service. Disposing of a household appliance separately avoids possible negative consequences for the environment and health deriving from inappropriate disposal and enables the constituent materials to be recovered to obtain significant savings in energy and resources. As a reminder of the need to dispose of household appliances separately, the product is marked with a crossed-out wheeled dustbin.
- Never dispose of used electronics with ordinary solid waste since they contain toxic substances.
- Always dispose of used electronics in accordance with the prevailing community regulations that apply to the disposal of electronics. If there are no regulations concerning electronics disposal, please dispose of the device in a waste bin for electronic devices.





WARRANTY

This Amplify™ Amplify™ ChargePro Series 20 000 mAh Powerbank With LED Display comes with a standard 12-month limited warranty against manufacturing defects and faults. Should the product be unboxed with any faulty parts, poor finishing, visible damage, or failure to perform due to a manufacturing defect or poor workmanship, please return it with your proof of purchase (till slip or invoice) to the store of purchase for an exchange, or repair, depending on the store's returns policy.

This warranty commences from the date of purchase.
Kindly retain your proof of purchase and the packaging for your warranty period.

NOTE:
The warranty does not apply to a product that:

a. It has failed due to excessive wear and tear beyond what is considered reasonable.
b. Has been misused or neglected.
c. Has been damaged accidentally or by Force Majeure, including fire and flooding.
d. Has been used or operated contrary to operating or maintenance instructions outlined in this manual.

The Store of Purchase / Seller cannot accept any returned products that have not been returned per this warranty or which do not follow their Returns Policy.

Please refer to the Store of Purchase / Sellers Returns Policy for details.
Please contact the store of purchase if you require assistance or have queries about your warranty.